


R-8 PORTER-CABLE Clarke RENTAL SANDER



ILL. #	PART #	Description
1	R802	Wheel Axle
2	R803	Collar
3	R805	Fan Shaft
4	R806	Fan Collar
5	R807	Fan Seal
6	R808	Fan Pulley
7	R809	Idler Shaft
8	R810	Drum Pulley
9	R811	Drum Shaft
10	R812	Shocks
11	R813	Drum Arm Cap
12	R814	Rubber Washer
13	R816	Motor Pin
14	R818	Brushes PC

ILL. #	PART #	Description
15	R819	LH Nut
16	R820	LH Nut
17	R822	Idler Pulley
18	CE12	Brush Cap
19	SW01	Wrenches
20	6266	Plug, Male
21	4731	Plug, Female
22	DU34	Twist Base
23	K600	HD Switch
24	S35	Rental Bag
25	3L240	Belt
26	4L290	Belt
27	R802	Wheel Axle