


Wolf Sander old Bona Super 8

Part #	Description
6005	Bearing
6202	Bearing
6206	Bearing
6345	Inlet
KTIN8	Bearing, Center Roller
KTIN434	Seal Outer
KTIN435	Seal Inner
SPR1125	Load Spring
WS04	clip set, top roller
WS08	center tube, 8"
WS09	center tube, 10"
WS20	cone roller, inner
WS21	cone roller, outer
WS28	clamp lever
WS39	link, top roller spring
WS77	handle rod
WS78	handle grip
WS80	Control handle grip
WS80A	control handle
WS80B	control handle link
WS81A	spacer
WS82	cable arm
WS82A	cable arm bracket
WS82B	spring
WS85	handle cover
WS86C	bushing
WS87A	feather handle grip
WS87B	feather handle link
WS87C	spring, feather handle
WS87D	bolt, eye
WS87E	spacrer
WS88	connecting piece
WS89	dust pipe
WS90	dust pipe elbow
WS94A	stud
WS94B	pin
WS107	top roller assembly, 8"
WS108	top roller assembly, 10"
WS113	spacrer
WS114	top roller pivot
WS115	spacer, convex
WS116	top roller support plate
WS121	tracking adjuster
WS122	top roller axle, 8"
WS123	top roller axle, 10"
WS144	spring, wheel, top roller
WS168	dust pipe support
WS192	motor mount nut
WS193	motor platform, 8"
WS194	motor platform, 10"
WS195	tension lever
WS196	belt guard plate 8"
WS197	adjuster knob
WS198	belt guard plate 10"
WS202	switch, rotary
WS202A	switch cover
WS202C	switch knob
WS205	capacitor, 60uf
WS210	spacer, motor bearing rotor
WS211	fan cover
WS213	bearing cover
WS214	pulley, motor, 8"
WS214A	pulley, motor, 10"
WS215	ring nut
WS217	fan, motor
WS218	end bell, fan side
WS219	motor
WS220	field
WS256	fine nut
WS278	voltmeter
WS279	motor box
WS280	power inlet box
WS281	handle, motor box
WS283	indicator light
WS283A	indicator light mount
WS283B	indicator light cover
WS285	E-stop box w/switch nut
WS285A	nut
WS285B	reducer



Part #	Description
WS285C	strain relief
WS287	E-stop mount plate
WS288	E-stop cord socket
WS289	E-stop cord plug
XABCC	Screw, dan
XABFD	Met. hex
XBAIO	Met. hex
XBAIU	Met. hex
XBBF	Met. dan
XBBFL	Met. dan
XBBGH	Met. dan
XBBHG	Met. dan
XBCGG	Met. screw, flat
XBCO	Met. screw, flat
XBCGJ	Met. screw, flat
XBCJL	#N/A
XBEGP	Met. screw, socket
XBEHG	#N/A
XBEHO	Met. screw, socket
XBEL	Met. screw, socket
XBFIL	Met. screw, butto
XBGHJ	Met. screw, flat socket
XBIJZ	Met. screw, stud
XBYFG	Met. screw, low socket
XBYHA	Met. screw, low socket
XBYHO	Met. screw, low socket
XBYI	Met. screw, low socket
XBYJ	Met. screw, low socket

Part #	Description
XBYL	Met. screw, low socket
XBYN	Met. screw, low socket
XBYO	Met. screw, low socket
XBYR	Met. screw, low socket
XBYT	Met. screw, low socket
XBYV	Met. screw, low socket
XBYW	Met. screw, low socket
XBYX	Met. Nut, hex
XBYZ	Met. Nut, hex
XCAF	Met. Nut, hex
XCB	Met. Nut, hex
XCC	Met. Nut, hex
XCD	Met. Nut, hex
XCE	Met. Nut, hex
XCF	Met. Nut, hex
XCG	Met. Nut, hex
XCH	Met. Nut, hex
XCI	Met. Nut, hex
XCL	Met. Nut, hex
XCM	Met. Nut, hex
XCN	Met. Nut, hex
XCO	Met. Nut, hex
XCP	Met. Nut, hex
XCR	Met. Nut, hex
XCS	Met. Nut, hex
XCT	Met. Nut, hex
XCU	Met. Nut, hex
XCV	Met. Nut, hex
XCW	Met. Nut, hex
XCX	Met. Nut, hex
XCY	Met. Nut, hex
X CZ	Met. Nut, hex